

Domestic System Daily Check

- Turn on the light located to the right of the entry door.
- View the floor in the basement thru the grate and be sure it is dry.
- Watch the individual pump green lights on the VFD and make sure they are staying off for a period of time. See the note below for details.
- If the pumps are operating normally, turn the light off and securely close the door.
- If the pumps seem to be cycling too fast or not at all, call one of the members of the board and report what you think may be a leak or system malfunction.
- Winter months: Check the outside temperature on the two thermometers on the north wall. If 33°F or less, please contact one of the board members.**

NOTE: Normally the pump light will stay off for several seconds and up to several minutes depending on how much water is being used. Checking the system early morning, mid morning, mid afternoon or late evening is best, as most are not using water at that time.